
Operating and installation instructions
Cooker hood



To prevent the risk of accidents or damage to the appliance, it is **essential** to read these instructions before it is installed and used for the first time.

en-GB

M.-Nr. 10 899 700

Contents

Warning and Safety instructions 4

Caring for the environment 11

Guide to the appliance 12

Modes of operation 14

Before using for the first time 15
Setting up Miele@home 15
Connecting via the app 16
Connecting via WPS 17
Sign out of WiFi (reset to factory settings) 18
Setting up Con@ctivity 19
Con@ctivity via the home WiFi network (Con@ctivity 3.0) 19
Con@ctivity via a direct WiFi connection (Con@ctivity 3.0) 20
Con@ctivity with direct wireless connection (Con@ctivity 2.0) 21

Operation (Automatic mode) 25
Cooking with Con@ctivity (Automatic mode) 25
Leaving automatic mode temporarily 27
Returning to automatic mode 27

Operation (Manual mode) 28
Cooking without Con@ctivity (Manual mode) 28
Switching the fan on 28
To select a power level 28
Selecting the run-on time 28
Switching the fan off 28
Dimming/switching the hob lighting on/off 29
Power management 29
Safety switch-off 30

Operation (Automatic and Manual modes) 31
Operating hours counter 31
Altering the operating hours counter for the grease filter(s) 31
Altering the charcoal filter operating hours counter 32
Reading the filter operating hours counter 32

Energy saving tips 33

Cleaning and care 34
Housing 34
Grease filters 35
Resetting the grease filter operating hours counter 37

Contents

Charcoal filters 37
Resetting the charcoal filter operating hours counter 38
Disposing of charcoal filters 38
Reactivatable charcoal filters 38

Installation 39
Before installation 39
Assembly parts 39
Installation instructions 39
Appliance dimensions 40
Safety distance between hob and cooker hood (S) 41
Installation recommendations 42

Electrical connection 43

After Sales / Warranty 44
Position of the data plate 44

Technical data 45
Special accessories for recirculation mode 45
Conformity declaration 46

Warning and Safety instructions

This appliance complies with all relevant local and national safety requirements. Inappropriate use can, however, lead to personal injury and damage to property.

To avoid the risk of accidents and damage to the appliance, please read these instructions carefully before using it for the first time. They contain important notes on the safety, installation, use and maintenance of the appliance. Miele cannot be held liable for non-compliance with these instructions.

Keep these instructions in a safe place and ensure that all users are familiar with the contents. Pass them on to any future owner of the appliance.

Correct application

▶ This cooker hood is intended for use in domestic households and similar working and residential environments.

▶ The cooker hood is not intended for outdoor use.

▶ It must only be used as a domestic appliance to extract vapours and remove odours from cooking.
Any other usage is not supported by the manufacturer and could be dangerous.

▶ Where a recirculation cooker hood is fitted above a gas hob, please ensure that there is an adequate supply of fresh air into the room in which it is installed. Please seek the advice of a qualified gas fitter (e.g. GasSafe in the UK) if necessary.

▶ The cooker hood can only be used by people with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they are supervised whilst using it, or have been shown how to use it in a safe way and recognise and understand the consequences of incorrect operation.

Safety with children

▶ Children under 8 years of age must be kept away from the cooker hood unless they are constantly supervised.

▶ Children 8 years and older may only use the cooker hood unsupervised if they have been shown how to use it safely and recognise and understand the consequences of incorrect operation.

▶ Children must not be allowed to clean or maintain the cooker hood unsupervised.

▶ Please supervise children in the vicinity of the cooker hood and do not let them play with it.

▶ The hob lighting is very intensive.
Ensure, in particular, that babies/small children do not look at the light.

▶ Danger of suffocation. Packaging, e.g. plastic wrappings, must be kept out of the reach of babies and children. Whilst playing, children could become entangled in packaging or pull it over their head and suffocate.

Technical safety

▶ Unauthorised installation, maintenance and repairs can cause considerable danger for the user. Installation, maintenance and repairs must only be carried out by a Miele authorised technician.

▶ A damaged appliance can be dangerous. Check it for visible signs of damage. Do not use a damaged appliance.

▶ The electrical safety of this appliance can only be guaranteed when correctly earthed. It is essential that this standard safety requirement is met. If in any doubt please have the electrical installation tested by a qualified electrician.

▶ Reliable and safe operation of this cooker hood can only be assured if it has been connected to the mains electricity supply.

▶ The connection data (voltage and frequency) on the data plate of the cooker hood must match the mains electricity supply in order to avoid the risk of damage to the cooker hood
Compare this before connecting the appliance to the mains. Consult a qualified electrician if in any doubt.

▶ Do not connect the appliance to the mains electricity supply by a multi-socket unit or an extension lead. These are a fire hazard and do not guarantee the required safety of the appliance.

▶ For safety reasons, this appliance may only be used after it has been built in.

▶ The cooker hood must not be used in a non-stationary location (e.g. on a ship).

▶ Touching electrical components and tampering with electrical and mechanical parts is highly dangerous to the user and can cause operational faults.
Only open the housing as described in the instructions given in the installation sheet and in the Cleaning and care section of this booklet. Under no circumstances should any other parts of the housing be opened.

▶ The manufacturer's warranty will be invalidated if the appliance is not repaired by a Miele approved service technician.

▶ Miele can only guarantee the safety of the appliance when genuine original Miele replacement parts are used. Faulty components must only be replaced by Miele spare parts.

▶ Do not pull on the mains connection cable. It must not be used for securing other components (such as a shelf).

▶ If the electrical connection cable is faulty it must only be replaced by a Miele authorised service technician to protect the user from danger.

▶ During installation, maintenance and repair work, the appliance must be disconnected from the mains electricity supply.

Correct use

▶ Never use a naked flame beneath the cooker hood. To avoid the danger of fire, do not flambé or grill over a naked flame.
When switched on, the cooker hood could draw flames into the filter. Fat deposits could ignite, presenting a fire hazard.

▶ The cooker hood can become damaged when exposed to excessive heat.

- When using the cooker hood over a gas hob, ensure that any burners in use are always covered by a pan. Switch the cooking zone off when a pan is removed, even for a short time.
- Select a pan which is suitable for the size of the burner.
- Regulate the flame so that it does not burn up the sides of the pan.
- Avoid overheating the pan (e.g. when cooking with a wok).

▶ Always switch the cooker hood on when a cooking zone is in use, otherwise condensation may collect in the hood, which could cause corrosion.

▶ Overheated oil and fat can ignite, causing fire damage to the cooker hood.
When cooking with oil or fat, chip pans and deep fat fryers etc, do not leave the pans unattended. Similarly, never leave an open grill unattended when grilling.

▶ Do not use the cooker hood without the filters in place. This way you will avoid the risk of grease and dirt getting into the appliance and hindering its smooth operation.

▶ The cooker hood can get very hot during cooking due to heat rising from the hob.
Do not touch the housing or the grease filters until the cooker hood has cooled down.

Correct installation

▶ Refer to the cooker or hob manufacturer's instructions as to whether a cooker hood may be operated above the cooker/hob.

▶ Safety regulations prohibit the fitting of a cooker hood over solid fuel stoves.

▶ An insufficient safety distance between the hob and the cooker hood can result in damage to the cooker hood.
The minimum safety distances between the top of the cooker or hob and the bottom of the cooker hood given in the "Installation" section of this booklet must be maintained, unless the hob manufacturer states that a greater safety distance is required.
If more than one cooking appliance is fitted beneath the cooker hood, and they have different minimum safety distances to the cooker hood, select the greater distance.

▶ The distances given in "Installation" must be observed when fitting the cooker hood.

Cleaning and care

▶ There is a risk of fire if the cooker hood is not cleaned as described in these operating instructions.

▶ Do not use a steam cleaning appliance to clean this appliance. The steam could reach electrical components and cause a short circuit.

Accessories

▶ Only use genuine original Miele accessories and spare parts with this appliance. Using accessories or spare parts from other manufacturers will invalidate the warranty and Miele cannot accept liability.

Disposal of the packing material

The packaging is designed to protect the appliance from damage during transportation. The packaging materials used are selected from materials which are environmentally friendly for disposal and should be recycled.

Recycling the packaging reduces the use of raw materials in the manufacturing process and also reduces the amount of waste in landfill sites.


Disposing of your old appliance


Electrical and electronic appliances often contain valuable materials. They also contain specific materials, compounds and components, which were essential for their correct function and safety. These could be hazardous to human health and to the environment if disposed of with your domestic waste or if handled incorrectly. Please do not, therefore, dispose of your old appliance with your household waste.



Please dispose of it at your local community waste collection / recycling centre for electrical and electronic appliances, or contact your dealer or Miele for advice. You are also responsible (by law, depending on country) for deleting any personal data that may be stored on the appliance being disposed of. Please ensure that your old appliance poses no risk to children while being stored prior to disposal.

Guide to the appliance







① Suspension cables

② Canopy

③ Grease filters

④ Controls
The symbols indicate sensor controls. Touch the sensor controls to select functions. A brief beep will sound for confirmation.

⑤ Hob lighting

⑥ Recirculation grille

⑦ Charcoal filters (x 4)

⑧ Sensor control for switching the fan on and off

⑨ Sensor control for the hob lighting

⑩ Sensor controls for selecting the fan power level

⑪ Sensor control for the run-on option

⑫ Operating hours control for the grease filters

⑬ Operating hours control for the charcoal filters

Modes of operation

Recirculation mode

This cooker hoods operates solely in recirculation mode.

The air is drawn in and cleaned first by the grease filters and then by four charcoal filters. The cleaned air is then recirculated back into the kitchen through ventilation grilles in the top of the cooker hood.

Setting up Miele@home

Prerequisite:

– Home WiFi network

Your cooker hood is equipped with an integrated WiFi module. The cooker hood can be connected to the household WiFi network.

You will then be able to operate the cooker hood via the Miele@mobile app.

If your Miele hob is connected to a home WiFi network, you can control the cooker hood automatically via the Con@ctivity function.

Before installing the cooker hood in its final location, ensure that the signal of your WiFi network is strong enough.

Please note that you cannot set up a WiFi connection at the same time as the wireless Con@activity 2.0 system.

Miele@mobile App

The Miele@mobile App is available to download free of charge from the Apple App Store® or from the Google Play Store™.




Connecting via the app

The Miele@mobile app can be used to connect to your network.

- Install the Miele@mobile app on your mobile device.

To log in you will need:

1. Your WiFi network password
2. Your cooker hood password



The password for your cooker hood consists of the last nine digits of the serial number. This can be found on the appliance's data plate.

The data plate is visible after removing the grease filter.



- Start signing the appliance on in the app. Follow the signing in instructions.

If requested to activate WiFi on the cooker hood, proceed as follows:


- Switch the cooker hood off.



- Press and hold the **B** control.



- Touch the lighting control at the same time ☼.



2 will light up constantly, **3** will flash on and off.

The cooker hood is ready for connection in the next two minutes.



- Follow the instructions in the app.



When successfully connected the **2** and **3** will light up constantly.



- Quit connection mode on the cooker hood by touching the Run-on control 5 15.

The cooker hood can now be operated via the app.


Connecting via WPS

Your WiFi router must support WPS (WiFi Protected Setup).


- Switch the cooker hood off.



- Press and hold the **B** control.




- Touch the lighting control at the same time ☼.




2 will light up constantly, **3** will flash on and off.

The WiFi connection must be started on the cooker hood at the same time as on the WiFi router.



- Press the **B** control on the cooker hood after a few seconds.




After a short while the **2** will light up constantly, and the **3** and the **B** will flash on and off.

The cooker hood is ready for connection in the next two minutes.



- Start the WiFi connection on your WiFi router.



When successfully connected the **2** and **3** will light up constantly.



- Quit connection mode on the cooker hood by touching the Run-on control 5 15.

The cooker hood can now be operated via the app.

If the connection fails, you have probably not connected WPS on your router quickly enough. Repeat the steps above.

Tip: If your WiFi router does not support WPS, please connect via the Miele@mobile app.

Before using for the first time

Sign out of WiFi (reset to factory settings)

To set up a new WiFi connection, the existing WiFi connection must be disconnected.


- Switch the cooker hood off.



- Press and hold the **1** control.



- Touch the lighting control at the same time ☼.




With an existing WiFi connection the **2** and the **3** will light up constantly.


The cooker hood is ready for disconnection in the next two minutes.



- Touch the **1** control.



2 will light up constantly, **3** will flash on and off.



After a few seconds the **2** and the **3** will flash on and off. The connection has now been disconnected.



- Quit disconnection mode on the cooker hood by touching the Run-on control 5 15.

The WiFi connection has now been disconnected. A new connection can now be set up.

Setting up Con@ctivity

Con@ctivity is the direct communication system between an electric Miele hob and a Miele cooker hood. It enables the cooker hood to operate automatically depending on the operational state of a Miele hob with onset controls.

– When the hob is switched on, the cooker hood lighting comes on automatically and then after a short time the fan also comes on.

– The cooker hood selects the power level automatically during cooking. The power level selected by the cooker hood depends on the number of cooking zones being used and their power levels.

– After switching the hob off the fan and the hob lighting will switch off automatically after a specified period of time.

See "Operation" for detailed information about this function.

This cooker hood can be operated with the Con@ctivity function via a WiFi connection (Con@ctivity 3.0) or via a wireless connection (Con@ctivity 2.0).

Con@ctivity via the home WiFi network (Con@ctivity 3.0)

Prerequisite:

– Home WiFi network

– WiFi enabled Miele hob

■ Connect the cooker hood and hob to your home WiFi network (see "Setting up Miele@home").

The Con@ctivity function will be activated automatically.

Con@ctivity via a direct WiFi connection (Con@ctivity 3.0)

Prerequisite:

– WiFi enabled Miele hob

If you do not have a home network, you can establish a direct connection between the hob and the cooker hood.

See the Hob instruction manual for details on how to connect them.

Instructions on how to connect the cooker hood are repeated in detail below.


■ Switch the cooker hood off.



■ Press and hold the **B** control.




■ Touch the **1** control at the same time.



2 will light up constantly, **3** will flash on and off.

The cooker hood is ready for connection in the next two minutes.

■ Start WiFi connection on the hob. For further details, see the hob operating instructions.



When successfully connected the **2** and **3** will light up constantly.



■ Quit connection mode on the cooker hood by touching the Run-on control 5 15.


Con@ctivity has now been activated.

With a direct WiFi connection, it is not possible to connect the hob and the cooker hood to a home network. Should this be required at a later date, the WiFi connection between the hob and the cooker hood must be disconnected (see "Sign out of WiFi").

Con@ctivity with direct wireless connection (Con@ctivity 2.0)

Prerequisite:

– Con@ctivity 2.0 enabled Miele hob



This cooker hood is supplied with a Con@ctivity 2.0 wireless stick ①.

The wireless stick can only be used with hobs that are fitted with a slot for the wireless stick to operate the Con@activity function.

- Check the installation instructions for the Con@ctivity 2.0 stick to ensure that it is compatible with your hob.

Please note that you cannot set up a WiFi connection at the same time as the wireless Con@activity 2.0 system.

Installing the Con@ctivity 2.0 stick

- See the relevant installation instructions provided with the Con@ctivity 2.0 stick.

Activating the wireless connection

The cooker hood and the hob must installed and operational.

Wireless connection must be activated on the cooker hood and the hob at the same time. Activation on the cooker hood is described below.
Activation on the hob is described in the relevant operating and installation instructions. Please refer to the operating instructions before starting.
Activate the cooker hood first, then the hob.

Before using for the first time

Activating the cooker hood

- The hob and cooker hood must be switched off.



- Touch the run-on control 5 15 for approx. 10 seconds until **1** lights up.
- Then touch in turn,



– the **1** control,




– then the **B** control,



– then the lighting control ☼.


The cooker hood is now in signing on/ off mode.




If a wireless connection has not yet been established, **2** and **3** will flash at the same time.
If a wireless connection has already been established, **2** and **3** will light up constantly (Con@ctivity 2.0 is already activated or a remote control is signed on).



- Touch the **B** control to activate Con@ctivity 2.0.



2 will light up constantly, **3** will flash on and off.



After a few seconds **2** and **3** with light up constantly, **B** will flash on and off.


The search for a wireless connection will start.

Activating the hob



- **While** the cooker hood is searching for a signal, start activating the hob. For further details, see the hob operating instructions.
- When the hob registers that a link has been established, exit activation on the hob.

Finish activation on the cooker hood



When successfully connected the **B** will go out, and the **2** and **3** will light up constantly.



- Confirm activation with the run-on control 5 15. All the indicator lights will go out.

The Con@ctivity 2.0 function is now ready for use.

If confirmation is not carried out within 4 minutes, activation will not take place.

Activation only takes place once. If appliances are disconnected from the mains, for example during a power cut, the activation process does not need to be repeated.

Activation failed

If the wireless connection cannot be established despite activating the cooker hood and the hob, both appliances must first be deactivated and then re-activated.

Deactivating wireless connection

- The hob and cooker hood must be switched off.



- Touch the run-on control 5 15 for approx. 10 seconds until **1** lights up.
- Then touch in turn,



– the **1** control,



– then the **B** control,



– then the lighting control .

The cooker hood is now in signing on/ off mode.




If a wireless connection has already been established, **2** and **3** will light up constantly.


Before using for the first time



■ Touch the **1** control to deactivate Con@ctivity 2.0.



2 will light up constantly, **3** will flash on and off.



After a few seconds **2** and **3** will start flashing on and off.

The wireless connection has now been deactivated.

■ To deactivate the hob, see the hob operating instructions.

Note that disabling the wireless connection will also deactivate any remote control function and this will have to be activated again.

When Con@ctivity 2.0 is active, the cooker hood always operates in Automatic mode (see "Setting up Con@ctivity 2.0").

If you wish to manually operate the cooker hood, see "Cooking without Con@ctivity.

Cooking with Con@ctivity (Automatic mode)

- Switch a cooking zone on at the power level you want.


The hob lighting will come on.

After a few seconds the fan will come on, first at power level **2**, then it will switch immediately to power level **1**.

The cooker hood selects the power level automatically during cooking.

This is determined by the total output of the hob, i.e, the number of cooking zones in operation and the power levels selected.

- If you select a higher power level or are using several cooking zones, the cooker hood will switch to a higher power level.
- When you reduce the power level or the number of cooking zones on the hob, the cooker hood power level is also reduced.



Examples for power levels **1** to **B**

Reaction time

The cooker hood reacts with a slight delay because altering the power level on the hob does not immediately result in a reduction or increase in cooking vapours.

Because the hob transmits the information to the cooker hood at intervals, this can also cause delays.

The reaction can vary from a few seconds to a couple of minutes.

Cooking process

■ If for example you switch on a cooking zone at the highest power level to heat a pan for frying and reduce the power level after approx. 10 seconds to 4 minutes *, a cooking process is recognised. (*60 seconds to 5 minutes for a HiLight hob.)

The cooker hood switches itself on and when the hob power level has been reduced, the hood switches to power level 3 and remains at that level for approx. 5 minutes.

After that the cooker hood power level is determined automatically by the Con@ctivity function.

■ You can select another power level manually before then.

Switching off

■ Switch off all cooking zones.

The cooker hood fan will reduce its power level in stages over the next few minutes and will then switch itself off.

This helps to neutralise any lingering vapours and odours in the air.

– From the Booster setting, the fan switches immediately to Level 3.

– From Level 3, it will switch to Level 2 after approx. 1 minute.

– From Level 2, it will switch to Level 1 after 2 minutes.

– After 2 minutes at Level 1 the fan switches itself off.

– After another 30 seconds, the hob lighting switches off.

The cooking process is then finished.

Leaving automatic mode temporarily

To leave automatic mode temporarily during cooking:

- manually select a different power level, or
- manually switch the cooker hood off, or
- activate the run-on function $^{5}\cap^{15}$ on the cooker hood. The fan will switch itself off after the selected run-on time, and the lighting will remain on.

The cooker hood functions can now be operated manually (see "Cooking without Con@ctivity").

Returning to automatic mode

The cooker hood will resume automatic mode:

- if the cooker hood has not been used for approx. 5 minutes after selecting a power level manually, or
- if the manually selected fan power level corresponds to the automatic one again, or
- the cooker hood fan and the hob have been switched off for at least 30 seconds.
  Automatic mode will resume next time the hob is switched on.

You can also operate the cooker hood manually for a complete cooking process.

- To do so switch the cooker hood fan on **before** the hob.
  If the cooker hood fan and the hob have been switched off for at least 30 seconds after cooking, automatic mode will resume next time the hob is switched on.

Cooking without Con@ctivity (Manual mode)

The cooker hood can be operated manually if:

– the Con@ctivity function is not activated.

– you have temporarily deactivated the Con@ctivity function (see "Temporarily exiting Automatic mode").

Switching the fan on

Switch the fan on as soon as you start cooking. This is to ensure that vapours are captured right from the start.

■ Touch the On/Off control ⏻.

The fan will come on at power level **2**.

To select a power level

For light to heavy cooking vapours and odours, select from power levels **1** to **3**.

For short periods of cooking food with intensive vapours and a strong aroma, e.g. when searing meat, select Booster setting **B**.

■ Select the power level required by touching a control from **1** to **B**.

Reducing power down from the Booster setting

If power management is activated (default setting), the fan automatically switches back to level **3** after 5 minutes.

Selecting the run-on time

It is advisable to run the fan for a few minutes after cooking has finished. This helps to remove any lingering vapours and odours from the air.

It also reduces the risk of residues accumulating in the cooker hood and any resultant odours.

The run-on function enables the fan to continue running for a pre-determined time before switching itself off automatically.

■ After you have finished cooking, touch the run-on option control 5 15.

– Once: the fan will switch itself off after 5 minutes (**5** lights up).

– Twice: The fan will switch itself off after 15 minutes (**15** lights up).

– If you touch the run-on option control 5 15 again, the fan will remain on (5 15 will go out).

Switching the fan off

■ Press the On/Off control ⏻ to switch the fan off.

Dimming/switching the hob lighting on/off

The hob lighting can be switched on and off and dimmed independently of the fan.

- Press the lighting sensor briefly to switch it on or off.

The lighting will switch on at maximum brightness.

- With the lighting switched on, press and hold the hob lighting sensor. The brightness will gradually dim until you release the control.
- Press and hold the lighting control again to increase the brightness to the level required and then release it.

Power management

The cooker hood features a power management system to help save energy. The fan power level is reduced and the lighting is switched off automatically.

– If the Booster setting has been selected, the fan will automatically switch to level 3 after 5 minutes.

– From levels 3, 2 or 1 the power will be reduced by one level after 2 hours and then in 30 minutes stages until the fan finally switches off.

– The hob lighting will switch off automatically after 12 hours.

You can deactivate Power management.
This can however result in increased electricity consumption.

Switching Power management on/off

- Switch off the fan and the lighting.
- Touch the run-on option control 5 15 for approx. 10 seconds, until **1** lights up in the power level display.
- Then touch in turn,

– the lighting control .

– the **1** control and then

– the lighting control .

If Power management is switched on, the **1** and **B** indicators light up constantly.
When it is switched off, the **1** and **B** indicators flash.

- Touch the **1** control to switch Power management off.

The **1** and **B** indicators will flash.

- Touch the **B** control to switch it on.

The **1** and **B** indicators will light up constantly.

- Confirm the setting with the run-on option control 5 15

All the indicator lights will go out.

If you don't confirm your selection within 4 minutes, the cooker hood will automatically revert to the original setting.

Safety switch-off

If Power management has been deactivated, the cooker hood will switch itself off automatically after 12 hours if it has been left on (fan and hob lighting).

- To switch it on again press the On/Off control or the lighting control .

Operating hours counter

The cooker hood registers the length of time it has been operated.

When the grease filter symbol or the charcoal filter symbol lights up, the operating hours counters are signalling that the filters need to be cleaned or changed. Further information about cleaning and replacing the filters and resetting the operating hours counter can be found under "Cleaning and care".

Altering the operating hours counter for the grease filter(s)

You can set the operating hours counter to suit the type of cooking you do.

It is set at the factory for 30 hours.

– Select a shorter time of 20 hours if you fry a lot.

– If you only cook occasionally, we recommend that you still select a short time. This is to prevent grease hardening on the filter(s) and making cleaning more difficult

– Select a longer time of 40 or 50 hours if you use very little fat for cooking.

■ Switch off the fan and the lighting.

■ Touch the run-on option control 5 15 and the Grease filter control at the same time.

The Grease filter symbol and one of the fan power level indicators will flash.

Fan power level indicators **1** to **B** show the time set:

1 ..... 20 hours

2 ..... 30 hours

3 ..... 40 hours

B ..... 50 hours

■ Touch the relevant control to select the duration required.

■ Confirm your choice by touching the Grease filter control .

All the indicator lights will go out.

If you don't confirm your selection within 4 minutes, the cooker hood will automatically revert to the original setting.

Altering the charcoal filter operating hours counter

You can set the operating hours counter to suit the type of cooking you do.

It is set at the factory for 180 hours of use before they need to be replaced.

- Switch off the fan and the lighting.
- Touch the run-on option control and the Charcoal filter control at the same time.

The Charcoal filter symbol and one of the fan power level indicators will flash.

Fan power level indicators **1** to **B** show the time set:

1..... 120 hours

2..... 180 hours

3..... 240 hours

B..... deactivated

- Touch the relevant control to select the duration required.
- Confirm your choice by touching the Charcoal filter control .

All the indicator lights will go out.

If you don't confirm your selection within 4 minutes, the cooker hood will automatically revert to the original setting.

Reading the filter operating hours counter

You can check the percentage of time set already used before the filter needs replacing.

- Switch the fan on with the On/Off control .
- Press and hold the Grease filter control or the Charcoal filter control .

One or more of the power level indicators will flash.

The number of fan power level indicators flashing shows the percentage of the operating time which has already been used up.

1 ..... 25 %

1 and **2** ..... 50 %

1 to **3** ..... 75 %

1 to **B** ..... 100 %

The number of operating hours used remains in the memory, even when the appliance is switched off or there is a power cut.

This cooker hood operates very efficiently and economically. The following will help you to save even more energy when using it:

- It is important to ensure that the kitchen is well ventilated during operation.
- Always cook with the lowest possible setting. This produces fewer cooking vapours, so you can use a lower cooker hood power level and therefore benefit from reduced energy consumption.
- Clean or change the filters at regular intervals. Heavily soiled filters reduce performance, increase the risk of fire and are unhygienic.
- Use the Con@ctivity function. The cooker hood will switch on and off automatically at the optimum power level for the cooking you are doing, which ensures low energy consumption.
- If you are operating the cooker hood manually, please note the following:
  - Check the power level selected on the cooker hood. A low power level is usually sufficient. Only use the Booster setting when necessary.
  - When a large volume of cooking vapours are being produced, switch to a high power level in good time. This is more efficient than operating the cooker hood for longer to try to capture cooking vapours which have already been distributed throughout the kitchen.
  - Make sure that you switch the cooker hood off after use.
    If cooking vapours and odours still need to be removed from the kitchen air after cooking, use the run-on function. The fan will switch off automatically after the selected run-on time.

⚠ Before proceeding with any maintenance or cleaning task, the cooker hood must be disconnected from the power supply, see "Warning and safety instructions".

Housing

General information

The surfaces and controls are susceptible to scratches and abrasion.
Please observe the following cleaning instructions.

- All external surfaces and controls can be cleaned using hot water with a small amount of washing-up liquid applied with a well wrung-out soft sponge or cloth.
- After cleaning, wipe the surfaces dry using a soft cloth.

Do not use:

– cleaning agents containing soda, acids, chlorides or solvents,

– abrasive cleaning agents, e.g. powder cleaners or cream cleaners and abrasive sponges, as well as pot scourers or sponges which have been used previously with abrasive cleaning agents. These will damage the surface material.

Important for appliances with stainless steel surfaces

- Stainless steel surfaces can be cleaned with a proprietary non-abrasive cleaning agent designed specifically for use on stainless steel.
- To help prevent re-soiling, a proprietary conditioning agent for stainless steel (available from Miele) can also be used. Follow the manufacturer’s instructions on the packaging.

Important for appliances with lacquered housing

- Please observe the general notes on cleaning earlier in this section.

Minor scratches on the surface are inevitable when cleaning the housing. Depending on the lighting in the kitchen, this may negatively affect the appliance's appearance.

Important for appliances with glass surfaces

- Glass surfaces can be cleaned using a proprietary non-abrasive cleaning agent designed specifically for use on glass.

Grease filters

⚠ Fire hazard!
Oversaturated grease filters are a fire hazard.
Clean the grease filters at regular intervals.

The re-usable metal grease filters in the appliance remove solid particles (grease, dust, etc.) from the kitchen vapours, preventing soiling of the cooker hood.

The grease filters must be cleaned at regular intervals.

Heavily soiled grease filters hinder air extraction and will lead to increased levels of soiling in the cooker hood and in the kitchen.

Cleaning interval


Accumulated grease solidifies over a longer period of time and makes cleaning more difficult. The grease filters should therefore be cleaned every 3 to 4 weeks.

The filter operating hours control reminds you to regularly clean the grease filters by illuminating the grease filter symbol ⊛.

- You can set the operating hours counter interval to suit the type of cooking you do (see "Operation").

Removing a grease filter

When handling a grease filter, be careful not to drop it.
This can result in damage to the filter and the hob below.
Make sure you hold the filter securely at all times when handling it.



- To take out a grease filter, release the locking clip on the filter, lower the filter approx. 45°, unhook it at the back and remove it.

Cleaning the grease filters by hand

- Clean the filters with a soft nylon brush in a mild solution of hot water and a small amount of washing-up liquid. Do not use "neat" washing up liquid.

Unsuitable cleaning agents

Unsuitable cleaning agents can cause damage to the surface of the filters if used regularly.
Do not use:

– cleaning agents containing descaling agents

– powder cleaners, cream cleaners

– aggressive multi-purpose cleaning agents or spray cleaners for grease

– oven sprays


Cleaning the grease filters in the dishwasher

- Place the grease filters upright or slightly inclined in the lower basket. Ensure the spray arm is not obstructed.
- Use a commercially available household dishwasher detergent.
- Select a dishwasher programme with a wash temperature between 50 °C and 65 °C.

Depending on the detergent used, cleaning the filters in a dishwasher may cause the inside filter surfaces to become discoloured. This will not affect the functioning of the grease filters in any way.

After cleaning

- After cleaning, leave the filters to dry on an absorbent surface before replacing them.
- When removing the filters for cleaning, also clean off any residues of oil or fat from the now accessible housing to prevent the risk of these catching fire.
- Replace the grease filters, making sure that the locking clips are facing down towards the hob.



- If a grease filter is inadvertently replaced upside down, insert a small screwdriver blade into the slit to disengage the clip.

Resetting the grease filter operating hours counter

After cleaning, the operating hours counter needs to be re-set.

- Whilst the fan is switched on, press the Grease filter control for approx. 3 seconds, until only the **1** is flashing.

The Grease filter symbol goes out.

If you want to clean the grease filters before the operating hours counter has reached its maximum:

- Touch the Grease filter control for approx. 6 seconds, until only the **1** is flashing.


Charcoal filters

Four charcoal filters must be fitted in addition to the grease filters. These are designed to absorb cooking odours.


The charcoal filters are fitted in the canopy from above.

Fitting/replacing charcoal filters

- Take the charcoal filters out of their packaging.



- Open the apertures for the charcoal filters.



- Insert the charcoal filters and close the apertures up again.

When to change the charcoal filters

- Always replace the charcoal filters when they no longer absorb kitchen odours effectively.
  They should, however, be replaced at least every 2 years.

The operating hours counter will remind you to replace the charcoal filters by lighting up the charcoal filter symbol.

Resetting the charcoal filter operating hours counter

After changing the charcoal filters, the operating hours counter needs to be reset.

- Touch the Charcoal filter control for approx. 3 seconds with the cooker hood switched on until only the indicator light for level **1** is flashing.

The Charcoal filter symbol will go out.

If you want to replace the charcoal filters **before** the operating hours counter has reached its maximum:

- Touch the Charcoal filter control for approx. 6 seconds until only the indicator light for level **1** is flashing.

Disposing of charcoal filters

- Used charcoal filters can be disposed of with the normal household waste.

Reactivatable charcoal filters

Reactivatable charcoal filters are available for this cooker hood. They can be used several times after being reactivated in the oven.

They are supplied with their own fitting and usage instructions which must be observed.


Charcoal filters are available to order via the Miele Webshop, the Miele Spare Parts Department (see end of this booklet for contact details) or from your Miele dealer.

The charcoal filters are listed under "Technical data" at the back of this booklet.

Before installation

⚠ Before installation, it is important to read the information given on the following pages as well as the "Warning and Safety instructions" at the beginning of this booklet.


Assembly parts



5x60+h0ae8x50


4 screws 5 x 60 mm and
4 plugs 8 x 50 mm
for securing the cooker hood to the ceiling.

The screws and plugs are suitable for use in concrete ceilings.
For other types of ceiling construction, alternative fixings will be required.
Make sure the ceiling is able to take the weight of the cooker hood.




dai27796

Drilling template
One of the cardboard inserts serves as the drilling template.




4 sets of ceiling fixings
for suspending the cooker hood, comprising 4 cables, 4 appliance fixings and 4 ceiling fixings.

The cables must not be used for securing other components such as a shelf.



08277310

3 cable clamps
for securing the mains connection cable to one of the suspension cables.



dai2791


1 strain relief
for securing the mains connection cable to one of the ceiling fixings.

Installation instructions

See enclosed Installation sheet for instructions on how to install this appliance.

Installation

Appliance dimensions



① Mains connection cable

Safety distance between hob and cooker hood (S)

When planning the installation height of your cooker hood, the minimum safety distance between the top of a cooker or hob and the bottom of the cooker hood is as follows, unless a greater distance is specified by the manufacturer of your cooking appliance.
See "Warning and Safety" instructions for further information.

Cooking appliance	Minimum distance S
Electric hob	450 mm
Electric grill, deep fat fryer (electric)	650 mm
Multi-burner gas hob, total output ≤ 12.6 kW, no burner > 4.5 kW	650 mm
Multi-burner gas hob, total output > 12.6 kW and ≤ 21.6 kW, no burner > 4.8 kW.	760 mm
Multi-burner gas hob, total output > 21.6 kW, or multi-burner gas hob where one burner > 4.8 kW.	Not possible
Single burner gas hob, output ≤ 6 kW.	650 mm
Single burner gas hob, output > 6 kW and ≤ 8.1 kW.	760 mm
Single burner gas hob, output > 8.1 kW	Not possible

Installation

Installation recommendations

– When deciding on the safety distance between the hob and cooker hood, please note that a distance of 650 mm above electric cookers/hobs may be preferable to give more working space under the hood.

– Account should also be taken of the height of the person who will be using the hood most often. They should have sufficient space to work comfortably at the hob, and be able to reach the cooker hood controls with ease.

– Please be aware that if positioned too high, extraction will be inefficient.

– To achieve optimum vapour extraction, the cooker hood must be centred over the hob, not to the side or behind it.

– The hob should be no wider than the cooker hood, and if possible, it should be narrower.

– The installation area must be easily accessible. The cooker hood should be easily accessible and easy to dismantle in the event that service is required. This should be taken into consideration when planning the position of cupboards, shelves, ceilings or features in the vicinity of the cooker hood.

All electrical work should be undertaken by a suitably qualified and competent person in strict accordance with current national and local safety regulations (BS 7671 in the UK).
Installation, repairs and other work by unqualified persons could be dangerous, for which the manufacturer cannot be held liable.
Ensure power is not supplied to the appliance until after installation or repair work has been carried out.
Do not connect the appliance to the mains electricity supply by an extension lead. These do not guarantee the required safety of the appliance.

The connection data is given on the data plate. This is visible when the grease filters have been removed. Ensure that this data matches the household mains supply.

Connection of this appliance should be made via a suitable isolator or a double pole fused spur connection unit which complies with national and local safety regulations and the On-Off switch should be easily accessible after the appliance has been built in. When switched off there must be an all-pole contact gap of 3 mm in the switch (including switch, fuses and relays according to EN 60335).

If the switch is not accessible after installation (depending on country), an additional means of disconnection must be provided for all poles.
For extra safety it is advisable to protect the appliance with a suitable residual current device (RCD). Contact a qualified electrician for advice.

Important
This appliance is supplied for connection to an a.c. 230 V single phase 50 Hz supply. The wires in the mains lead are coloured in accordance with the following code:

Green/yellow .....earth

Blue ..... neutral

Brown .....live

WARNING:
THIS APPLIANCE MUST BE EARTHED

After Sales / Warranty

In the event of a fault which you cannot remedy yourself, please contact your Miele dealer or the Miele Service Department.

Contact details for Miele are given at the end of this booklet. N.B. A call-out fee will be charged for service visits where the problem could have been resolved as described in these instructions.

When contacting your dealer or Miele, please quote the model and serial number of your appliance.
These are shown on the data plate.

Position of the data plate

The data plate is visible after removing the grease filters.

Warranty: U.K.

In the U.K., the appliance warranty is valid for 2 years from the date of purchase. However, you must activate your cover by calling 0330 160 6640 or registering online at www.miele.co.uk.

Please note that telephone calls may be monitored and recorded for training purposes.

Warranty: Other countries

For information on the appliance warranty specific to your country please contact Miele. See end of this booklet for contact details.

Fan motor	2 x 72 W
Hob lighting	4 x 3 W
Total connected load	156 W
Voltage	AC 230 V
Fuse rating	5 A
Mains connection cable length	1.8 m
Weight	33 kg

WiFi module

Frequency band	2.412 - 2.462 GHz
Maximum transmitting power	< 100 mW

Wireless module (ZigBee)

Frequency band	2.405 - 2.48 GHz
Maximum transmitting power	< 10 mW

Special accessories for recirculation mode

Charcoal filter set DKF 21-1 or DKF 21-R (reactivatable). The sets contain four charcoal filters.

Technical data

Conformity declaration

Miele hereby declares that this cooker hood complies with Directive 2014/53/EU.

The complete text of the EU declaration of conformity is available from one of the following internet addresses:

– Products, Download from www.miele.co.uk

– For service, information, operating instructions etc. go to https://www.miele.com.au/domestic/customer-information-385.htm and enter the name of the product or the serial number.

Note for test institutes

Data quoted in the following data sheets was calculated in accordance with the following standards EN 61591 and EN 60704-3. For test purposes the distance maintained between the test zone/hob and the underside of the cooker hood was 600 mm and the voltage used was 230 V.

Data sheet for household cooker hoods

In acc. with delegated regulation (EU) No. 65/2014 and regulation (EU) No. 66/2014

MIELE	
Model name / identifier	DA 6708 D
Annual Energy Consumption (AEC_{hood})	80,6 kWh/year
Energy efficiency class	C
Energy efficiency index (EEI_{hood})	83,3
Fluid Dynamic Efficiency (FDE_{hood})	15,4
Fluid Dynamic Efficiency class	
A (most efficient) to G (least efficient)	D
Lighting Efficiency (LE_{hood})	60,0 lx/W
Lighting Efficiency class	
A (most efficient) to G (least efficient)	A
Grease Filtering Efficiency	91,2%
Grease Filtering Efficiency class	
A (most efficient) to G (least efficient)	B
Airflow at best efficiency point	348,7 m^3/h
Air flow (min. speed)	250 m^3/h
Air flow (max. speed)	470 m^3/h
Air flow (intensive or boost setting)	620 m^3/h
Max. air flow (Q_{max})	620 m^3/h
Air pressure at best efficiency point	216 Pa
Airborne acoustical A-weighted sound power emissions (min. speed)	54 dB
Airborne acoustical A-weighted sound power emissions (max. speed)	67 dB
Airborne acoustical A-weighted sound power emissions (intensive or boost setting)	74 dB
Electrical power input at best efficiency point	136,0 W
Power consumption in off mode (P_o)	W
Power consumption in standby mode (P_s)	0,35 W
Nominal power of lighting system	12,0 W
Average illumination of the lighting system on the cooking surface	720 lx
Time increase factor	1,4

United Kingdom
Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre Tel: 0330 160 6600
E-mail: mielecare@miele.co.uk
Internet: www.miele.co.uk

Australia
Miele Australia Pty. Ltd.
ACN 005 635 398
ABN 96 005 635 398
1 Gilbert Park Drive
Knoxfield, VIC 3180
Tel: 1300 464 353
Internet: www.miele.com.au

China
Miele (Shanghai) Trading Ltd.
1-3 Floor, No. 82 Shi Men Yi Road
Jing' an District
200040 Shanghai, PRC
Tel: +86 21 6157 3500
Fax: +86 21 6157 3511
E-mail: info@miele.cn,
Internet: www.miele.cn

Miele (Hong Kong) Limited
41/F - 4101, Manhattan Place
23 Wang Tai Road
Kowloon Bay, Hong Kong
Tel: (852) 2610 1025
Fax: (852) 3579 1404
Email:
customerservices@miele.com.hk
Website: www.miele.hk

India
Miele India Pvt. Ltd.
Ground Floor
Copia Corporate Suites
Plot No. 9, Jasola
New Delhi - 110025
Tel: 011-46 900 000
Fax: 011-46 900 001
E-mail: customercare@miele.in
Internet: www.miele.in

Ireland
Miele Ireland Ltd.
2024 Bianconi Avenue
Citywest Business Campus
Dublin 24
Tel: (01) 461 07 10
Fax: (01) 461 07 97
E-Mail: info@miele.ie
Internet: www.miele.ie

Malaysia
Miele Sdn Bhd
Suite 12-2, Level 12
Menara Sapura Kencana
Petroleum
Solaris Dutamas No. 1
Jalan Dutamas 1
50480 Kuala Lumpur, Malaysia
Phone: +603-6209-0288
Fax: +603-6205-3768

New Zealand
Miele New Zealand Limited
IRD 98 463 631
Level 2, 10 College Hill
Freemans Bay, Auckland 1011
New Zealand
Tel: 0800 464 353
Internet: www.miele.co.nz

Singapore
Miele Pte. Ltd.
163 Penang Road
04 - 03 Winsland House II
Singapore 238463
Tel: +65 6735 1191
Fax: +65 6735 1161
E-Mail: info@miele.com.sg
Internet: www.miele.sg

South Africa
Miele (Pty) Ltd
63 Peter Place, Bryanston 2194
P.O. Box 69434, Bryanston 2021
Tel: (011) 875 9000
Fax: (011) 875 9035
E-mail: info@miele.co.za
Internet: www.miele.co.za

Taiwan
K.E. & Kingstone Co., Ltd.
6th Fl., No. 120, Sec. 2
Jianguo N. Rd.
Taipei, Taiwan
TEL: +886 2 2502-7256
FAX: +886 2 2502-3077
E-mail: kenk@kenk.com.tw
Website:
www.kenk.com.tw/ke/miele

Thailand
BHIRAJ TOWER at EmQuartier
43rd Floor Unit 4301-4303
689 Sukhumvit Road
North Klongton Sub-District
Vadhana District
Bangkok 10110, Thailand

United Arab Emirates
Miele Appliances Ltd.
Gold & Diamond Park
Office No. 6-217
Sheikh Zayed Road
P.O. Box 11 47 82 - Dubai
Tel. +971 4 3044 999
Fax. +971 4 3418 852
800-MIELE (64353)
E-Mail: info@miele.ae
Website: www.miele.ae

Manufacturer: Miele & Cie. KG, Carl-Miele-Straße 29, 33332 Gütersloh, Germany

Miele

DA 6708 D

CE en-GB M.-Nr. 10 899 700 / 00