
Operating instructions

Refrigerator

Read the operating instructions before switching on for the first time



7085 473-01

MKv

LIEBHERR

Content

Noise emissions from the appliance 14
Disposal notes 14
Description of the appliance 14
Safety instructions and warnings 15
Other features 15
Range of appliance use 16
Climate rating 16
Setting up 16
Appliance dimensions 16
Electrical connection 16
Operating and control elements 17
Energy consumption 17
Temperature increase after a power failure 17
Switching the appliance on and off 17
Interior temperature 17
Power failure alarm 17
Door open alarm 18
Setting the delay time for the door open alarm 18
Audible warning signal settings 18
Alarm messages 18
Alarm test 19
Calling up stored alarm events and reading the temperature progression 19
Resetting the stored alarm events HAn 19
Resetting the recorded temperature progression rt 19
Example of an alarm query 20
Keypad lock 20
Setting the real time clock 21
Conversion from summer to winter time 21
Enabling/disabling automatic conversion from summer to winter time 21
Changing the network address 21
Resetting the parameters to factory settings 21
Interior light (MKv 3913) 22
Safety lock 22
Defrosting 22
Setting the display indication for the defrost phase 22
Activating the defrost function manually 22
Cleaning and disinfection 22
Malfunctions 23
Possible error messages in the display 23
Shutting your appliance down 23
External alarm 24
Floating alarm output 24
RS485 interface 24
Changing over door hinges 25

⚠ Important

The maximum load per grid shelf is 45 kg.

Noise emissions from the appliance

The noise level while the appliance is operating is below 70 dB(A) (relative noise level 1 pW).

Disposal notes

The appliance contains reusable materials and should be disposed of properly - not simply with unsorted household refuse. Appliances which are no longer needed must be disposed of in a professional and appropriate way, in accordance with the current local regulations and laws.

When disposing of the appliance, ensure that the refrigerant circuit is not damaged to prevent uncontrolled escape of the refrigerant it contains (data on type plate) and oil.

- Disable the appliance.
- Pull out the mains plug.
- Cut through the connection cable.

⚠ WARNING

Danger of suffocation due to packing material and plastic film!

Do not allow children to play with packaging material.

Take the packaging material to an official collection point.


A rechargeable battery is installed in the appliance.

Disposal instructions for batteries

The battery must be removed when you wish to dispose of the appliance and sent for separate waste treatment for batteries.

Do not damage or short circuit the battery.

Description of the appliance



Safety instructions and warnings

- To prevent injury or damage to the unit, the appliance should be unpacked and set up by two people.
- In the event that the appliance is damaged on delivery, contact the supplier immediately before connecting to the mains.
- To guarantee safe operation, ensure that the appliance is set up and connected as described in these operating instructions.
- Disconnect the appliance from the mains if any fault occurs. Pull out the plug, switch off or remove the fuse.
- When disconnecting the appliance, pull on the plug, not on the cable.
- Only carry out repair and other work on the appliance when the mains plug has visibly been disconnected.
- Any repairs and work on the appliance should only be carried out by the customer service department, as unauthorised work could prove highly dangerous for the user. The same applies to changing the mains power cable.
- Do not allow naked flames or ignition sources to enter the appliance. When transporting and cleaning the appliance, ensure that the refrigerant circuit is not damaged. In the event of damage, make sure that there are no ignition sources nearby and keep the room well ventilated.
- Do not stand on the plinth, drawers or doors or use them to support anything else.
- This appliance can be used by children of 8 years old and over, and also by persons with restricted physical, sensory or mental capacity or lack of experience and knowledge, if they are supervised or have been instructed on safe use of the appliance and understand the resulting risks. Children must not be allowed to play with the appliance. Cleaning and user maintenance must not be carried out by children without supervision.
- Avoid prolonged skin contact with cold surfaces or chilled/frozen food. This could cause pain, numbness and frostbite. In the case of prolonged skin contact, protective measures should be taken, e.g. gloves should be worn.
- Do not store explosives or sprays using combustible propellants such as butane, propane, pentane, etc. in the appliance. Electrical components might cause leaking gas to ignite. You may identify such sprays by the printed contents or a flame symbol.
- Do not use electrical appliances inside the appliance.
- If you have a lockable appliance, do not keep the key near the appliance or within reach of children.
- The appliance is designed for use in enclosed areas. Do not operate the appliance outdoors or in areas where it is exposed to splash water or damp conditions.
- Do not seal ventilation openings on the appliance housing or enclosure.
- The LED light strip illuminates the interior of the appliance. It is not suitable for lighting a room.
- Do not install the appliance in the immediate vicinity of an air-conditioning unit. The appliance should also not be operated under a wall-mounted air-conditioning unit.
- The appliance is **not** suitable for storing blood bottles pursuant to DIN 58371.
- In special fields of application which are subject to their own standard, the user is responsible for complying with this standard.
- Only use the mechanical devices or other aids recommended by the manufacturer to help speed up the defrosting process.
- Ensure that the refrigerant circuit pipes will not be damaged.

Other features

- Audible and visual temperature alarm (adjustable limits).
- Audible and visual door open alarm.
- Floating contact for connection to a remote monitoring system.
- Serial interface (RS485) for external temperature and alarm documentation.
- Maximum/minimum interior temperatures are stored.
- Last 3 temperature alarms are saved with time, date and duration of alarm.
- Last 3 power cuts are saved with time, date and duration of power cut.
- Safety thermostat to avoid temperatures below +2°C.

It is essential to use these safety facilities to avoid damage to stored items. These facilities must not be deactivated or decommissioned!

Range of appliance use


The appliance is designed for storing and cooling pharmaceuticals to DIN 58345 as long as the following conditions are satisfied:

- The appliance only complies with DIN 58345 if the battery of the power failure alarm integrated in the appliance is fully charged (see section entitled "Electrical connection").
- The appliances only satisfies the requirements of DIN 58345 with its factory temperature setting. If the temperature setting is adjusted (which can only be done by the service technician), its compliance with DIN 58345 will be void.

The appliance is **not** suitable for use in explosion-hazard areas.

Climate rating

The climate rating indicates at what room temperature the appliance may be operated to achieve full cooling capacity and what the maximum humidity level in the area around the appliance may be to ensure that no condensation forms on the exterior housing.




The climate rating is indicated on the type plate.

	Max. room temperature	Max. relative humidity
3	25 °C	60 %
4	30 °C	55 %
5	40 °C	40 %
7	35 °C	75 %
The minimum room temperature at the place of installation is 10°C.		

	Max. room temperature
SN	+10°C to +32°C
N	+16 °C to +32 °C
ST	+16 °C to +38 °C
T	+16 °C to +43 °C
SN-ST	+10 °C to +38 °C
SN-T	+10 °C to +43 °C


Setting up

- Avoid positioning the appliance in direct sunlight or near cookers, radiators and similar sources of heat.
- The floor on which the appliance stands should be horizontal and level. Compensate for uneven floors with the adjustable feet.
- Do not cover ventilation openings or grille. →



- Standard EN 378 specifies that the room in which you install your appliance must have a volume of 1 m^3 per 8 g of R 600a refrigerant used in the appliance, so as to avoid the formation of inflammable gas/air mixtures in the room where the appliance is located in the event of a leak in the refrigerant circuit. The quantity of refrigerant used in your appliance is indicated on the type plate on the inside of the appliance.

Appliance dimensions



Electrical connection

Only operate the appliance with **alternating current (AC)**.


The permissible voltage and frequency are indicated on the type plate. The position of the type plate is shown in the section entitled **Description of the appliance**.

The socket must be properly earthed and protected by a fuse.

The tripping current of the fuse must be between 10 A and 16 A.

The socket must not be situated behind the appliance and must be easily accessible.

Do not connect the appliance using an extension cable or extension socket.



Do not use stand-alone inverters (conversion of direct current to alternating/three-phase current) or energy-saving plugs. Risk of damage to the electronic control system!

- Connect the appliance to the mains - the display reads **OFF**.

Note

It will take 24 hours for the batteries in the power failure alarm to become fully charged.

Instructions for decommissioning the appliance

When decommissioning the appliance, it is essential to follow the instructions in the section entitled "**Shutting your appliance down**".

Otherwise, the power failure alarm will be activated when the mains plug is disconnected.

Operating and control elements



On/Off button (switching the appliance on and off)

Selection buttons

Defrost button (for manually activating the defrost function)

Keypad lock

Button for calling up stored alarm events

Audible alarm Off button

Interior light on/off button (MKv 3913)

Enter button

Symbols in the display

Compressor is running

LED flashing - refrigeration unit switches on after a delay. The compressor will start automatically after the pressure in the refrigerant circuit has equalised.

Fan is running

Appliance is defrosting

Temperature display via product sensor is activated

LED flashing and Etc appears in the display. The real time clock must be reset.

The interior light is switched on

The display means that the power supply and interior temperature of the appliance are recorded.

If flashes in the display, there has either been a power failure or the temperature in the appliance exceeded the permissible range.

Alarm function

The appliance has suffered a fault. Contact the customer service department.

Energy consumption
Temperature increase after a power failure

Model	MKv 3910	MKUv 3913
Energy consumption pursuant to K 2040 and DIN 58345	0.8 kWh/24h	1.5 kWh/24h
Temperature increase after a power failure from +5°C to +8°C pursuant to K 2040	30 minutes	30 minutes
Temperature increase after a power failure from +5°C to +10°C pursuant to DIN 58345	50 minutes	30 minutes

Switching the appliance on and off

Connect the appliance to the mains. Display = **OFF**.

Switching the appliance on

Press for approx. 5 seconds - Display = **ON**.

No alarm is displayed or sounded when the appliance is switched on for the first time.

If the appliance is disconnected from the mains for a long time after it has been switched on for the first time and if the temperature inside the appliance rises above the upper alarm limit, this will be detected as a fault by the electronic control system (appears in the display).

When the appliance is switched on again, this display must be reset as shown below.

Press .

Press + for 5 seconds. Display = rES

The LED will now light up permanently.

Press for 5 seconds.

The electronic control system will switch back to normal operating mode.

Switching the appliance off

Press for approx. 5 seconds - Display = OFF

Interior temperature

The temperature inside the appliance is set to +5°C (+/-3K) as required by DIN 58345 and cannot be changed.

Important note

Items must not be stored in the appliance until the temperature has reached 5°C.

Power failure alarm

In the case of a power failure, the audible warning signal will sound and btP will be shown in the display.

If appears in the refrigerator's display, the temperature has risen above the upper alarm limit of + 8°C.

Check the temperature progression as described in the section entitled

Calling up stored alarm events

and then make a decision on what you wish to do with the items stored in the refrigerator.

Door open alarm

When the door is opened, the LED lights up and the temperature display begins to flash.

When the door has been left open for more than 60 seconds, the LED begins to flash, and dor and the temperature indication flash alternately in the display.

The audible warning signal sounds (unless the audible warning signal function has been deactivated).

If the door has to stay open for longer in order to insert items to be cooled, cancel the audible warning signal by pressing button .

Setting the delay time for the door open alarm

The time before the audible warning signal sounds after the door has been opened can be adjusted.

Press for 5 seconds. Display = dG

Press ∧ until dBd appears in the display.

Press . Display = 1 Setting range = 1 - 5 minutes.

Use button ∨ or ∧ to select the desired setting.

Press . Display = dBd

Press for 5 seconds.

The electronic control system will switch back to normal operating mode.

Audible warning signal settings

The audible warning signal will be muted for the current alarm after the button has been pressed. Complete the following steps if you want the audible warning signal to reactivate automatically.

Press for 5 seconds. Display = dG

Press ∨ until ASn appears in the display.

Press . Display = 0

Press ∨. Display = 1

Press . Display = ASn

Automatic reactivation of the audible warning signal is now active.

The time before the audible warning signal sounds again must be set.

Press ∧. Display = ASd

Press . Display = 1 Setting range = 1 - 120 minutes.

Use button ∨ or ∧ to select the desired setting.

Press . Display = ASd

Press for 5 seconds.

The electronic control system will switch back to normal operating mode.

Alarm messages

1. LED flashes in the display

If appears in the display, the appliance has a fault. Consult your nearest customer service point.

2. LED flashes in the display; the display reads HI or LO

The interior is too warm (HI) or too cold (LO).

The audible warning signal sounds (unless the audible warning signal function has been deactivated).

Note
The alarm parameters can be adjusted. See **Adjusting the alarm parameters**.

3. HA / HF / flashes in the display

There has been a power cut (**HF**) of some length or the interior was too warm or too cold (**HA**) during a certain period of time.

Up to three alarm events can be stored and called up.

Alarm test

This test checks the function of the internal and any external connected alarm device.

The appliance does not stop its refrigerating function during this test.

Press 🔔 + ∨ for 5 seconds.

- The display will change to a temperature value of 0.2°C below the set upper alarm limit.
- The temperature value will now rise by 0.1°C every 2 seconds.
- When the upper alarm limit is reached, H10 will appear in the display. An external alarm unit connected to the floating alarm output will now be activated.
- The temperature value will continue to rise up to 0.2°C above the upper alarm limit.
- The same process will take place automatically for the lower alarm limit. L10 will appear in the display.

The LED 🔔 will be lit during the test.

The electronic control system will switch back to normal operating mode.

Cancelling the test prematurely

Press 🔔 for 5 seconds.

Note
If the values of the upper and lower alarm limit (**AL** and **AH** in the section entitled "**Adjusting the alarm parameters**") are set to **0**, H- - and L- - will appear in the display during this test.

Calling up stored alarm events and reading the temperature progression

Press 🔔 (LOG). Display = HAn

Scroll through the list using ∨ or ∧.

HAn	Number of temperature alarms
HA	Last temperature alarm
HA1	Last temperature alarm but one
HA2	Temperature alarm before HA1
HFn	Number of power cuts
HF	Last power cut
HF1	Last power cut but one
HF2	Power cut before HF1
rt	Period in hours in which the maximum and minimum interior temperatures were measured
rH	Maximum (highest) measured temperature
rL	Lowest measured temperature

Select the required item using the ⚙ button. Press this button again to return to the list.

You can exit the menu at any time by pressing 🔔 for 5 seconds.

If no button is pressed within 60 seconds, the electronic control system switches back automatically.

Resetting the stored alarm events HAn

Press 🔔 (LOG). Display = HAn

Press 🔔 (LOG) + ∧ for 5 seconds. Display = rES.

Press 🔔 for 5 seconds.

The electronic control system will switch back to normal operating mode.

Resetting the recorded temperature progression rt

Press 🔔 (LOG). Display = HAn

Press the button ∨ or ∧ until rt appears in the display.

Press ⚙. Display = 0 - 999

Press ∨ for 5 seconds. Display = rES.

The values for rH and rL (highest and lowest measured interior temperature) are then reset to the current interior temperature.

Press 🔔 for 5 seconds.

The electronic control system will switch back to normal operating mode.

Example of an alarm query

Situation: HA/HF/ flashes in the display.

Press . Display= HAn

Press . Display = 0

There has not been an alarm status with a too high or too low temperature. You must switch to display HFn.

Press . Display = HAn

Press until HFn appears in the display.

Press . Display = 1 1 power failure has occurred.

Press . Display = HFn

Press . Display = HF Last power failure.

Press . Display = Y00 (year)

Press . Display = M00 (month 1-12)

Press . Display = d00 (day 1-31)

Press . Display = h00 (hour 0-23)

Press . Display = n00 (minute 0-59)

Press . Display = t00 (Period of time in minutes)

Press + for 5 seconds. Display = rES

The LED will now light up permanently.

HA/**HF** is cancelled in the display.

The electronic control system is now ready for the next alarm.

Press for 5 seconds.

The electronic control system will switch back to normal operating mode.

Keypad lock

The keypad lock ensures that no unintentional changes are made to the electronic control system.

Setting a PIN code for the keypad lock function

Press for 5 seconds. Display = dG

Press until P 1 appears in the display.

Press . Display = 0

Use button or to choose a PIN code between 1 and 999.

Press . Display = P 1

Press for 5 seconds.

The electronic control system will switch back to normal operating mode.

Activating the keypad lock

Press for 5 seconds. Display = 0

Use button or to select the PIN code.

Press . Display = loc

All buttons except and are locked.

If an incorrect PIN code is entered, the electronic control system switches back to normal operation without activating the keypad lock.

Deactivating the keypad lock

Press for 5 seconds. Display = 1

Use button or to select the PIN code.

Press . Display = unl

All functions are enabled.

If an incorrect PIN code is entered, the keypad lock remains active.

Setting the real time clock

The real time clock is preset (CET). For a different time zone, the time must be adjusted manuall.

Press 🔔 for 5 seconds. Display = d6

Press ∨. Display = tc

Press ⚙. Display = Y00 (year)

Press ⚙. Display = 00

Set the year by pressing the ∨ ∧ buttons.

Press ⚙.

Press ∧. Display = M00 (month 1-12)

Press ⚙. Display = 00

Set the month by pressing the ∨ ∧ buttons.

Press ⚙.

Press ∧. Display = d00 (day 1-31)

Press ⚙. Display = 00

Set the day by pressing the ∨ ∧ buttons.

Press ⚙.

Press ∧. Display = u00 (days of the week)
(1 = Monday, 7 = Sunday)

Press ⚙. Display = 00

Set the day of the week by pressing the ∨ ∧ buttons.

Press ⚙.

Press ∧. Display = h00 (hour 0-23)

Press ⚙. Display = 00

Set the hour by pressing the ∨ ∧ buttons.

Press ⚙.

Press ∧. Display = n00 (minute 0-59)

Press ⚙. Display = 00

Set the minutes by pressing the ∨ ∧ buttons.

Press ⚙.

Press 🔔 for 5 seconds.

The electronic control system will switch back to normal operating mode.

When Etc appears in the display, the real time clock must be reset.

Conversion from summer to winter time

Conversion to summer time is carried out automatically by the electronic control system on the last Sunday in March at 2 o'clock in the morning.

Conversion to winter time is carried out automatically by the electronic control system on the last Sunday in October at 2 o'clock in the morning.

In order to enable the new time, the appliance must be switched off and on after each of the times specified above.

Enabling/disabling automatic conversion from summer to winter time

Press 🔔 for 5 seconds. Display = d6

Press ∨ until dSE appears in the display.

Press ⚙. Display = 1

Use button ∨ or ∧ to select the desired setting.

0 = deactivated 1 = activated

Press ⚙. Display = dSE

Press 🔔 for 5 seconds.

The electronic control system will switch back to normal operating mode.

Changing the network address

When connecting several appliances via the RS485 interface, each appliance must have its own network address.

Press 🔔 for 5 seconds. Display = d6

Press ∨ until H0 appears in the display.

Press ⚙. Display = 1

Use button ∨ or ∧ to change the network address (1-207).

Press ⚙. Display = H0

Press 🔔 for 5 seconds.

The electronic control system will switch back to normal operating mode.

Resetting the parameters to factory settings

The alarm limits and sensor calibration values can be reset to the factory settings using this function.

Press ⏻ for 5 seconds. Display = **OFF**.

Press ∧ + ⚙ for 5 seconds..

Display = bt0 .

Wait 10 seconds!

Remove the plug.


Keep 🔔 pressed and connect the mains plug.

Display = bnl

Press ⚙. Display = Std

The electronic control system will switch back to normal operating mode.

Interior light (MKv 3913)



The interior light can be switched on and off using the button.Keep the button pressed for approx. 3 seconds.


The light intensity of the LED light corresponds to laser class 1/1M.

Important

The light cover may only be removed by customer service staff.

If the cover is removed, do not look directly at the light through optical lenses from close distance. This can damage your eyes.

Safety lock



The lock in the appliance door is equipped with a safety mechanism.

Locking the appliance

- Insert the key as shown by arrow **1**.
- Turn the key 90°.

To unlock the appliance, the same procedure must be repeated in the same order.

Defrosting

The appliance defrosts automatically.

Setting the display indication for the defrost phase

Press for 5 seconds. Display = dG

Press until dG appears in the display.

Press . Display = I

Use button or to select the desired setting.

0 = Symbol + alternating display of dEF and the current temperature in the interior of the appliance.

1 = Symbol + temperature before the start of the defrost phase.

2 = Symbol + dEF.

Press . Display = dG

Press for 5 seconds.

The electronic control system will switch back to normal operating mode.

Activating the defrost function manually

If the door has been left slightly open for a long time, a layer of ice may form in the interior and on the cooling plate. The defrost function can then be activated manually.

Press for 3 seconds. Display = + dFb

The electronic control system will automatically switch back to normal operating mode.

Display = dFE

Cleaning and disinfection

Clean the appliance at least twice per year


Always switch off the appliance before cleaning and disinfecting it.

Disconnect the appliance from the mains.

- Only disinfect the appliance with ethyl alcohol-based products.
- First clean the soiled areas and grid shelves with a damp cotton cloth.
- Clean the interior container, grid shelves and outer walls with lukewarm water, ethyl alcohol-based cleaning products or water-based household cleaning products.

  Do not use chemical solvents or any cleaning agents containing sand or acid.

Do not use steam cleaners because of the risk of injury and damage.



- Ensure that no cleaning water penetrates into the electrical components or ventilation grille.
- The dust should be removed from the refrigeration unit and heat exchanger - metal grid at the back of the appliance - once a year.
- Do not damage or remove the type plate on the inside of the appliance. It is very important for servicing purposes.
- The appliance's materials are only resistant to the cleaning products listed above.
- Regular cleaning and disinfection prevents severe soiling.

Malfunctions

You may be able to rectify the following faults by checking the possible causes yourself:

- **Appliance does not function:**

– Is the appliance switched on?

– Is the plug correctly fitted in the mains socket?

– Is the fuse intact?

- **Loud running noise:**

– Is the appliance set up firmly on the floor?

– Does the appliance cause nearby items of furniture or objects to vibrate? Please note that noises caused by the refrigerant circuit cannot be avoided.

- **The temperature is not low enough:**


– Is the temperature setting correct (see "Setting the temperature")?

– Does the separately installed thermometer show the correct reading?

– Is the ventilation system working properly?

– Is the appliance set up too close to a heat source?

If none of the above causes apply and you cannot rectify the fault yourself, contact the nearest customer service department stating the type designation ①, service number ② and appliance number ③ as indicated on the type plate.




The position of the type plate is shown in the section entitled **Description of the appliance**.

Possible error messages in the display

Error code	Error	Action
E0, E1, E2, rE	Temperature sensor defective	Contact the customer service department
EE, EF	Electronic control system error	Contact the customer service department
dOr	Appliance door open for too long	Close appliance door
HI	Temperature inside appliance too high (too warm)	Check that the door has been closed properly. If the temperature does not drop, contact the customer service department.
LO	Temperature inside appliance too low (too cold)	Contact the customer service department
Etc		Reset the real time clock (see "Setting the real time clock")
HF, HA	There has been a power cut of some length or the interior was too warm or too cold during a certain period of time.	See **Calling up stored alarm events and reading the temperature progression**
AFr	Temperature around the product sensor < 0°C	Contact the customer service department

Shutting your appliance down



If the appliance is to be left switched off for any length of time, complete the following steps to disconnect the power failure alarm battery from the electronic control system.

Press ⏻ for 5 seconds. Display = **OFF**.


Press ∧ + ⚙ for 5 seconds..

Display = bt0 .

Wait 10 seconds!

Remove the plug.

The display will be switched off.




Note

If the display is not switched off, press the button on the power supply unit. ⟶

Clean the appliance and leave the door open in order to prevent unpleasant smells.


External alarm



We recommend connecting the appliance to an external alarm device.


There are various connection options at the back of the appliance.

The appliance may only be connected to an external alarm device by trained personnel.



Terminating resistor
When connecting several appliances via the RS485 interface, the terminating resistor must remain on the last appliance. **Remove the terminating resistors from the appliances in between.**

Note
The connectors are secured with screws. To remove the connectors, undo the left and right screws.



Floating alarm output

These three contacts can be used to connect the appliance to an optical or acoustic alarm device.

The connection is designed for a maximum of **42 V/8 A DC** from a safety extra-low voltage (SELV) source (**minimum current: 150 mA**).

Important

When supplying mains voltage to the floating alarm contact, the technical safety requirements of standard EN 60335 will not be satisfied.

N.O

Alarm output


Connection for a visual warning light or an acoustic alarm signal.

N.C

Operating light
Connection for a control lamp to indicate that the appliance is in normal mode.

COM

External power supply unit
42 V/8 A DC maximum
Minimum current: 150 mA




RS485 interface

Rx- / Tx-

Send/Receive data cable (negative pole)

Rx+ / Tx+

Send/Receive data cable (positive pole)



GND


Earth cable

Changing over door hinges


1. Unscrew the hinge bracket.

Important: The door mounting has a spring mechanism enabling the door to close by itself. The hinge bracket turns to the left when the screws are undone.


2. Pull the door out at the bottom and lift off.



3. Screw on the handle.
The handle and screws are supplied in the accessory pack.




4. Transfer pin on hinge bracket to the opposite side.



5. Transfer upper hinge components to the opposite side.

6. Transfer covers to the opposite side.



7. Mount door on hinge pin and close.

8. Insert hinge bracket in lower door mounting. Turn hinge bracket by 90° - spring is compressed. Screw on hinge bracket.

